



OPERATORS MANUAL FOR Mi-T-M®
WC-SERIES
Water Cannon



CAUTION

RISK OF INJURY!

READ MANUAL BEFORE OPERATING!

This manual is an important part of the Water Cannon and must remain with the unit when you sell it!

CONTENTS

INTRODUCTION.....	3
CONTENTS.....	4
SPECIFICATIONS.....	4
IMPORTANT SAFETY WARNINGS.....	5-7
FLOW CHART.....	8
DESCRIPTION OF WATER FLOW.....	9
FEATURES.....	10-11
INSTALLATION.....	12-13
PRE-START CHECKLIST.....	14
OPERATION.....	15
TROUBLESHOOTING.....	16-17
ACCESSORIES.....	18
STATEMENT OF WARRANTY.....	19

WARNING

This product contains one or more chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

INTRODUCTION

Congratulations on the purchase of your new Mi-T-M Water Cannon! Mi-T-M Water Cannons are designed to be the pre-wash phase of a heavy duty cleaning system. The Water Cannon sprays high volumes of water, ranging from 100 to 300 gallons per minute, onto large equipment. The immense flow of water easily removes excess dirt and grime, bringing the equipment to a stage capable of being cleaned by a pressure washer.

Mi-T-M Water Cannons can be used in a variety of environments, including:

*Rental Yards
Heavy Equipment Dealers
Trucking Facilities
Military Bases
Truck Rental Fleets
Forklift Washing Operations
Aircraft Maintenance & Restoration
Shipyards
Mining Operations*

The information in this operator's manual was compiled for your benefit. By reading and following the simple safety, installation, operation, maintenance and troubleshooting steps described in this manual, you will receive years of trouble free operation from your new Mi-T-M Water Cannon. The contents of this manual are based on the latest product information available at the time of publication. Mi-T-M reserves the right to make changes in price, color, materials, equipment, specifications or models at any time without notice.

! IMPORTANT !

These paragraphs are surrounded by a "SAFETY ALERT BOX". This box is used to designate and emphasize Safety Warnings that must be followed when operating this Water Cannon. Accompanying the Safety Warnings are "signal words" which designate the degree or level of hazard seriousness. The "signal words" used in this manual are as follows:

DANGER: Indicates an imminently hazardous situation which, if not avoided, WILL result in death or serious injury.

WARNING: Indicates a potentially hazardous situation which, if not avoided, COULD result in death or serious injury.

CAUTION: Indicates a potentially hazardous situation which, if not avoided MAY result in minor or moderate injury.



The symbol set to the left of this paragraph is a "Safety Alert Symbol". This symbol is used to call attention to items or procedures that could be dangerous to you or other persons using this equipment.

ALWAYS PROVIDE A COPY OF THIS MANUAL TO ANYONE USING THIS EQUIPMENT. READ ALL INSTRUCTIONS BEFORE OPERATING THIS WATER CANNON AND ESPECIALLY POINT OUT THE "SAFETY WARNINGS" TO PREVENT THE POSSIBILITY OF PERSONAL INJURY TO THE OPERATOR.

Once the unit has been uncrated, immediately write in the serial number of your unit in the space provided below.

SERIAL NUMBER _____

Inspect for signs of obvious or concealed freight damage. If damage does exist, file a claim with the transportation company immediately. Be sure that all damaged parts are replaced and that the mechanical and electrical problems are corrected prior to operation of the unit. If you require service, contact Mi-T-M Customer Service.

CALL OUR TOLL-FREE NUMBER

800-553-9053

for the Sales or Service Center nearest you!

Please have the following information available for all service calls:

1. Model Number
2. Serial Number
3. Date and Place of Purchase

CONTENTS OF THE WATER CANNON

Carefully unpack your new Mi-T-M Water Cannon. Contact the freight line if a damage claim is required on any component. The following items are the basic equipment sent with your Water Cannon.

1. Remote Control Start/Stop
2. Float Level Controls
 - a. Low water float (blue).
 - b. Fresh water float (red).
3. Manual
4. Surge Suppressor (for WC-300-0ME3 only).

- OPTIONS:**
- Check Valve (Flapper Type)
 - Gate Valve
 - Suction Strainer
 - Monitor
 - Hose Reel for 100' hose
 - Hose- 100' x 1 1/2"
 - Nozzle- Adjustable
 - Nozzle- Smooth Bore
 - Bale- Ball Shutoff

SPECIFICATIONS

MODEL #	WC-100-0ME3	WC-150-0ME3	WC-300-0ME3	WC-400T-0ME3
FLOW (GPM)	100	150	300	400
PSI	60	100	100	125
HORSEPOWER	7.5	15	40	40
VOLTAGE	208-230	208-230	208-230	208-230
AMPERAGE	21.4-19.6	43.0-38.0	111.0-97.4	100
HZ.	60	60	60	60
PHASE	3	3	3	3
INLET	2" NPT	3" NPT	5" Flanged	3" Flanged
OUTLET	2" NPT	2.5" NPT	3" NPT	2 1/2" NPT
OPTIONS	WX-0002 (460V/9.8 AMPS)	WX-0003 (460V/19 AMPS)	WX-0004 (460V/48.7 AMPS)	460V/60 AMPS
UNIT DIMENSIONS LxWxH	42 x 20 x 66	45 x 21 x 67	57.5 x 28 x 74.5	61 x 36 x 60
UNIT WEIGHT (LBS.)	328	451	975	1178



IMPORTANT SAFETY WARNINGS

WARNING: WHEN USING THIS PRODUCT, BASIC PRECAUTIONS SHOULD ALWAYS BE OBSERVED, INCLUDING THE FOLLOWING:



READ ALL SAFETY WARNINGS BEFORE USING YOUR Mi-T-M WATER CANNON


HAZARD	POTENTIAL CONSEQUENCE	PREVENTION
<p>RISK OF ELECTRIC SHOCK OR ELECTROCUTION</p> 	<p>Serious injury or death could occur if the Water Cannon is not properly grounded. Your Water Cannon is powered by electricity and may cause electric shock or electrocution if not installed properly.</p>	<p>Installation of this unit, including all electrical connections, must comply with all local, state and national codes.</p>
	<p>Electrical shock may occur if the Water Cannon is not operated properly.</p>	<p>This product must be grounded. Connect to a GFCI circuit breaker when available. If the unit should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. Do not ground to a gas supply line.</p>
	<p>Serious injury or death may occur if electrical repairs are attempted by unqualified persons.</p>	<p>Improper connection of the equipment-grounding conductor can result in a risk of electrocution. Check with a qualified electrician or service personnel if you are in doubt as to whether the system is properly grounded.</p>
		<p>Always be certain the unit is receiving proper voltage (+/- 5% of the voltage listed on the nameplate). Before installing electrical connections, be certain the power switches are in the "OFF" position.</p>
		<p>Keep all connections dry.</p>
		<p>DO NOT spray on or into electrical installations of any kind! This includes electrical outlets, light bulbs, fuse boxes, transformers, the water cannon itself, etc..</p>
		<p>DO NOT allow metal components of the Water Cannon to come in contact with live electrical components.</p>
		<p>Never operate the Water Cannon with safety guards/covers removed or damaged. Ensure all electrical covers are securely in place when unit is operating.</p>
		<p>Any electrical wiring or repairs performed on this Water Cannon should be done by Authorized Service Personnel in accordance with National and Local electrical codes.</p>
		<p>Before opening any electrical enclosure, always shut off the Water Cannon. Disconnect the Water Cannon from the power source. If the power disconnect is not in sight, lock it in the open position and tag it to prevent power usage. (Never assume the Water Cannon is safe to work on just because it is not operating! Always disconnect from the power source.)</p>



IMPORTANT SAFETY WARNINGS

READ ALL SAFETY WARNINGS BEFORE USING WATER CANNON



HAZARD	POTENTIAL CONSEQUENCE	PREVENTION
<p>RISK OF EXPLOSION OR FIRE</p> 	<p>Serious injury or death could occur from an explosion or fire caused by a system electric spark.</p>	<p>This unit must be placed in an area that is well ventilated, free of flammable vapors, combustible dust, gases or other combustible materials.</p>
<p>RISK OF BURSTING</p> 	<p>Serious injury or death could occur from bursting caused by excessive pressure in the system.</p> <p>Serious injury may occur if attempting to start the Water Cannon when the pump is frozen.</p>	<p>Do not use this Water Cannon to pump flammable material! An explosion could occur.</p> <p>In freezing temperatures, the unit must be protected from freezing. Do not start the Water Cannon if it has been in a freezing environment without first allowing the pump to thaw.</p>
<p>RISK OF BURNS</p> 	<p>Serious injury may occur from touching the electrical motor. This area can remain hot for some time after the Water Cannon is shutdown.</p>	<p>Never allow any part of your body to contact the electrical motor until cooled.</p>
<p>RISK FROM MOVING PARTS</p> 	<p>Serious injury may occur to the operator from moving parts on the Water Cannon.</p>	<p>Do not operate the unit without all protective covers in place.</p> <p>Follow the maintenance instructions specified in the manual.</p>



IMPORTANT SAFETY WARNINGS

READ ALL SAFETY WARNINGS BEFORE USING WATER CANNON




HAZARD	POTENTIAL CONSEQUENCE	PREVENTION
<p>RISK OF INJECTION OR SEVERE CUTTING INJURY</p> 	<p>Serious injury or death could occur from water spray penetrating the skin.</p>	<p>Keep clear of nozzle and spray! Never put your hand, fingers or body directly over the spray nozzle.</p> <p>Never point the discharge spray at yourself or anyone else.</p> <p>Always keep operating area clear of all persons.</p> <p>SEEK EMERGENCY MEDICAL CARE if the spray appears to have penetrated the skin! DO NOT TREAT AS A SIMPLE CUT!!</p> <p>Hoses should be inspected daily for signs of wear. If evidence of failure exists, promptly replace all suspect hoses to prevent the possibility of injury from the spray. If a hose or fitting is leaking, NEVER PLACE YOUR HAND DIRECTLY ON THE LEAK.</p> <p>Before removing the spray nozzle or servicing the unit, ALWAYS shut off the unit and release trapped pressure. (Even after you shut off the unit, there is pressurized water left in the pump and hose until you release it).</p>
<p>RISK OF BODILY INJURY</p> 	<p>Serious injury or death may occur from the contact force of an uncontrolled water nozzle.</p> <p>Serious injury can occur from loose debris being propelled at a high speed from the water nozzle.</p> <p>Injury may occur if the operator loses his balance caused by the thrust of water traveling through the water nozzle.</p> <p>Injury may occur from the water cannon.</p>	<p>Do not start or operate the unit until an operator is securely bracing the spray nozzle.</p> <p>ALWAYS wear protective goggles when operating the water cannon to shield the eyes from flying debris.</p> <p>DO NOT direct spray toward fragile materials such as glass. Shattering could occur.</p> <p>Stay alert-watch what you are doing. Do not operate the unit when fatigued or under the influence of alcohol or drugs.</p> <p>NEVER open the water nozzle unless securely braced.</p> <p>DO NOT overreach or stand on unstable support.</p> <p>Wet surfaces can be slippery, wear protective foot gear and keep good footing and balance at all times.</p> <p>NEVER open the water nozzle while on a ladder or roof.</p> <p>Do not direct spray at people or pets. The force of the water can knock a person down.</p> <p>DO NOT DRINK THE WATER IN THE WATER CANNON!! This is non-potable water and is not suitable for consumption.</p> <p>DO NOT allow children to operate this unit.</p> <p>Know how to stop the water cannon quickly. Be thoroughly familiar with controls.</p> <p>DO NOT leave the water cannon unattended. Shut off the water cannon before leaving.</p>

!SAVE THESE INSTRUCTIONS!

WATER CANNON FLOW CHART

WC FLOW-063099-DCE



- 1. Inlet Filter/Strainer
- 2. Inlet Check Valve
- 3. Inlet Plumbing
- 4. Centrifugal Pump
- 5. Prime Chamber
- 6. Cyclone Separator
(not available WC-400T-0ME3)
- 7. Flow Switch
- 8. Discharge Plumbing
- 9. Surge Suppressor
- 10. Hose Reel
- 11. Stationary Monitor

- 12. Nozzle
- 13. Spray Stream
- 14. Wash Pad
- 15. Collection Pit
- 16. Solids Collection Area
- 17. Weir
- 18. Screens
- 19. Sump Pit
- 20. Low Water Float
- 21. Fresh Water Float
- 22. Fresh Water Solenoid


- Prime Valve* 1
- Inlet Valve* 2
- Discharge Valve* 3
- Separator Drain Valve* 4

- Pressure Gauge** 1
- Pressure Gauge** 2

DESCRIPTION OF WATER FLOW

Water is drawn through the **Inlet Filter/Strainer (1)**, past the **Inlet Check Valve (2)** and into the **Inlet Plumbing (3)** when the **Centrifugal Pump (4)** is operating.

The **Centrifugal Pump (4)** will need to be primed at initial start-up or whenever the water is drained from the system. Open **Prime Valve 1** on the **Prime Chamber (5)** and fill the stand pipe with water. Close **Prime Valve 1** and start the **Centrifugal Pump (4)**. Water travels from the **Centrifugal Pump (4)**, through the **Inlet Valve 2** and into the **Cyclone Separator (6)**.



CYCLONE SEP-061599-DCE

Once inside the **Cyclone Separator (6)** (not available on WC-400T-0ME3), the water begins to accelerate in a downward circular motion. The force of the spiral action sends the heavier solid particles to the outer walls of the **Cyclone Separator (6)**. Once away from the spiraling action, the solid particles drop to the collection chamber where they are periodically purged from the **Separator Drain Valve 4**, positioned at the bottom of the **Cyclone Separator (6)**. This **Separator Drain Valve 4** controls the flow rate in which the separated solids flow back into the **Collection Pit (15)**. The spiraling water continues to move down the chamber until it reaches an inverted cone at the bottom of the chamber. This cone allows the *rotation* of the spiral to remain constant, but forces the *direction* of the spiral to move upward and through the center of the initial whirl.

The water then moves out of the top of the **Cyclone Separator (6)** and past a **Flow Switch (7)** that is designed to activate an adjustable timing circuit that will shut off the **Centrifugal Pump (4)** if there is low or no flow. If flow is sufficient, a **Centrifugal Pump (4)** pressure reading will register on **Pressure Gauge 1**. **Pressure Gauge 2** indicates the pressure after the **Cyclone Separator (6)**. After passing the two pressure gauges, the water travels through **Discharge Valve 3** and into the **Discharge Plumbing (8)**.


NOTE: The WC-300-0ME3 model is equipped with a **Shock Suppressor (9)** in the discharge plumbing to protect the system from pressure spikes. (The **Shock Suppressor (9)** is available as an Option for the WC-100-0ME3 & WC-150-0ME3).

The **Discharge Plumbing (8)** directs the water to a workstation which will be equipped with a **Hose Reel (10)** or a **Stationary Monitor (11)** connected to a water **Nozzle (12)**. The force and volume of the **Spray Stream (13)** from the **Nozzle (12)** works to remove excess dirt from the equipment on the **Wash Pad (14)**, allowing dirt laden water to fall into the **Collection Pit (15)** placed next to the **Wash Pad (14)**. Heavier debris will fall to the bottom of the **Collection Pit (15)**, settling in the **Solids Collection Area (16)** while the remaining water continues to flow through several removable **Weirs (17)** equipped with debris collection **Screens (18)**. This process removes the heavier debris from the water as it returns to the **Sump Pit (19)**.

There are two floats in the **Sump Pit (19)** that register low water level.

- The **Low Water Float (20)** (blue and normally open in the down position) will turn off the **Centrifugal Pump (4)** to prevent cavitation when the water level is extremely low.
- The **Fresh Water Float (21)** (red and normally closed in the down position) signals to open the **Fresh Water Solenoid (22)** to maintain the correct water level in the **Sump Pit (19)**.


100/150 GPM WATER CANNON FEATURES



- | | | |
|---------------------------------|----------------------------------|-----------------------------|
| 1. Inlet Filter/Strainer | 14. Centrifugal Pump | 27. Uni-Strut Bracket |
| 2. Flapper Inlet Check Valve | 15. Square Tube | 28. Uni-Strut Clamp |
| 3. Leveling Bolt | 16. Fresh Water Solenoid | 29. Inlet Valve |
| 4. Anchor Hole | 17. Fresh Water Unions | 30. Outlet Pressure Gauge |
| 5. Foot Level Support | 18. Control Panel | 31. Flow Switch |
| 6. Plumbing Support | 19. Decal-Warn/ Caution/ Operate | 32. Outlet Valve |
| 7. Channel Iron | 20. Decal-Valve & Gauge Numbers | 33. Outlet Union |
| 8. Base Plate w/Motor Slots | 21. Prime Valve | 34. Low Water Float (Blue) |
| 9. Electric Motor | 22. Inlet Pressure Gauge | 35. Fresh Water Float (Red) |
| 10. Decal-Warning: Installation | 23. Separator Inlet Union | 36. Remote Switch |
| 11. Inlet Union | 24. Purge Union | |
| 12. Prime Chamber | 25. Purge Valve | |
| 13. Angle Support | 26. Cyclone Separator | |

WCFEAT150-061599-DCE

300 GPM WATER CANNON FEATURES




WCFEAT300-061599-DCE

- | | | |
|---------------------------------|---------------------------------|-----------------------------|
| 1. Inlet Filter/Strainer | 14. Centrifugal Pump | 27. Purge Valve |
| 2. Flapper Inlet Check Valve | 15. Square Tube | 28. Cyclone Separator |
| 3. Leveling Bolt | 16. Fresh Water Solenoid | 29. Uni-Strut Clamp |
| 4. Anchor Hole | 17. Fresh Water Unions | 30. Uni-Strut Bracket |
| 5. Foot Level Support | 18. Control Panel | 31. Inlet Valve |
| 6. Plumbing Support | 19. Decal-Warn/Caution/Operate | 32. Outlet Pressure Gauge |
| 7. Channel Iron | 20. Vic-Tolic Union | 33. Flow Switch |
| 8. Base Plate | 21. Prime Valve | 34. Outlet Valve |
| 9. Electric Motor | 22. Decal-Valve & Gauge Numbers | 35. Outlet Union |
| 10. Decal-Warning: Installation | 23. Vic-Tolic Drain "T" | 36. Shock Suppressor |
| 11. Inlet Flange | 24. Inlet Pressure Gauge | 37. Low Water Float (Blue) |
| 12. Angle Support | 25. Separator Inlet Union | 38. Fresh Water Float (Red) |
| 13. Prime Chamber | 26. Purge Union | 39. Remote Switch |

INSTALLATION

INSTALLATION:

1. A collection pit system must already be an established structure before installing the Water Cannon. A well designed pit system is critical for the proper operation of the Water Cannon. Consult your Mi-T-M dealer for installation requirements.
2. Do not allow the Water Cannon to be exposed to freezing temperatures. If any part of the Water Cannon becomes frozen, excessive pressure may build up in the system creating a risk of bursting.
3. Place the Water Cannon in an enclosed area on a concrete surface next to the Collection Pit.
4. Install the appropriate floor anchors through the predrilled adjustable feet of the Water Cannon.
5. Use the bolts sized 1/2"-13, between the feet and feet levelers to level the Water Cannon. Lock the feet in position with the two bolts sized 3/8"-16.



PLUMBING CONNECTIONS:

1. **SUCTION LINE:** Draws water from the collection pit for distribution throughout the Water Cannon system.
 - a. Install the foot valve onto the Inlet Pipe in the collection pit.
 - b. Connect the plumbing from the Water Cannon Pump Inlet to the Collection Pit.
2. **FRESH WATER INLET & OUTLET:** Draws water from an outside source for use in filling the collection pit in the event of evaporation.
 - a. Connect the required plumbing to the Fresh Water Inlet and Outlet.
3. **DISCHARGE LINE:** Sends pressurized, filtered water to the Water Cannon nozzle.
 - a. Connect the required plumbing from this outlet to the hose reel/monitor.
4. **PURGED WATER LINE:** Sends filtered debris back to the collection pit.
 - a. Plumb 3/4" back to the collection pit.

FLOAT CONNECTIONS:

1. Attach the two floats in the collection pit. Allow a 2" tether and enough room for them to move freely without interfering with the plumbing.
 - a. **FLOAT 1:** Fresh Water Float (Red). Signals the Fresh Water Makeup Solenoid to open or close to maintain the correct water level in the pit.
 1. Height of this float must be adjusted to the individual pit system.
 - b. **FLOAT 2:** Low Water Shut-off (Blue). Signals the system to shutdown when the pit water level is too low for proper operation.
 1. Attach this float above the suction strainer of the Water Cannon pump inlet.



INSTALLATION

ELECTRICAL CONNECTIONS:

1. A qualified electrician must install the electrical system.
 - a. Verify the electrical supply at the power source is off.
 - b. Run water tight conduit:
 1. From the Control Panel to the Remote box.
 2. From the local disconnect to the Control Panel. The electrician will need to drill holes in the Control Panel for the conduit.
 - c. Wiring for the floats should be run through conduit to the box.
 - d. Make connections to the terminal strips as shown below.
 - e. Bump start the motor to ensure the rotation is going in the direction of the arrow decal affixed to the motor.



WARNING
RISK OF ELECTROCUTION!
ENSURE ALL CONNECTIONS
ARE DRY AND THE POWER
SUPPLY IS OFF.



208/230/460 VOLT
 3 PHASE

WCFIELDINSTALL-050900-DCE

STOP

TO ENSURE YOUR WATER CANNON OPERATES SAFELY AND EFFICIENTLY, COMPLETE THE PRE-OPERATION CHECKLIST BEFORE PROCEEDING.

PRE-OPERATION CHECKLIST


Before proceeding, answer all the questions on this checklist.	YES	NO
CODES:		
1. Does the electrical wiring meet all codes?		
2. Does plumbing meet all codes?		
LOCATION:		
1. Is the unit located on a hard level surface?		
2. Is the unit located in a large ventilated area?		
3. Is the unit located near the Sump Pit?		
ELECTRICAL:		
1. Is the unit properly grounded?		
2. Does the power supply, voltage and amperage match the data plate?		
3. Are the control floats, flow switch and remote switch(es) properly installed?		
4. Is the motor rotation correct?		
PLUMBING:		
1. Is the plumbing sized correctly?		
2. Is the check valve installed near the collection pit?		
3. Are all unions tightened?		
GENERAL:		
1. Have all operators using this unit read and understood this entire manual?		
2. Has the unit been installed by qualified service people who followed the instructions listed in this manual?		

IF "NO" WAS MARKED TO ANY OF THESE QUESTIONS, CORRECT THE SITUATION BEFORE OPERATING.

OPERATION

VALVE POSITION

BALL VALVE
OPERATION



PRIMING THE SYSTEM:

1. Ensure the Sump Pit is filled with fresh water.
2. Position the valves on the Water Cannon system in the priming mode:

<u>VALVE #</u>	<u>VALVE POSITION</u>	<u>USE</u>
1 Prime.	Open.	Fills Prime Chamber to prime the pump.
2 Inlet.	Open.	Controls incoming water flow.
3 Discharge.	Open.	Controls outgoing water flow to nozzle.
4 Drain.	Closed.	Controls solids removal from system.

3. Ensure there is power to the Control Panel.
4. Fill the Prime Chamber with water. After filling, close Prime Valve 1.
5. Ensure an operator is holding the water nozzle / hose, and that it is pointed in a safe direction away from self or others.
6. Once the water nozzle is secure, press the green "Start" button on the Control Panel or the start button on the Remote to turn on the unit. **DO NOT ALLOW THE MOTOR/PUMP TO RUN FOR MORE THAN 15 SECONDS WITHOUT A FLOW OF WATER.** Repeat steps 2-6 until water exits the nozzle and the pressure gauge maintains an elevated pressure rating.

OPERATION:

1. Once the unit is primed, there will normally be a difference of 10 PSI between gauges 1 and 2. If not, slowly close the Discharge Valve #3 until the pressure Gauge 1 reads 10 PSI higher than Gauge 2.
2. Partially open the Separator Drain Valve 4 to allow collected debris to continually flush from the separator. (Degree may vary.)
3. Your Mi-T-M Water Cannon is now operating at maximum performance.
4. To completely purge the separator, fully open the Separator Drain Valve 4 and allow the system to purge for approximately 3 minutes. This should be done periodically to ensure the separator is completely flushed of debris.

NOTE: A safety feature has been built into the unit which will cause a complete shutdown if there is no water flow for 3-5 minutes.

SHUTDOWN:

1. The Water Cannon can be shutdown by pressing the red Stop button on the Control Panel or the Stop button on the Remote.

TROUBLESHOOTING

SYMPTOM	PROBABLE CAUSE	REMEDY
<i>ELECTRICAL</i>		
No power at the Control Panel.	Power failure to the Control Panel.	Check circuit breaker at power source or contact your local distributor.
	Improper or loose wire connections.	Check wire diagram/schematic.
<i>CENTRIFUGAL PUMP</i>		
Centrifugal Pump motor will not start or stops.	Circuit overload/breaker has tripped.	Reset breaker or replace fuse at power source.
	Improper or loose wire connections.	Check wire diagram/schematic.
	Improper or loose motor connections.	Check and tighten connections.
	Water Cannon motor overload.	Allow motor to cool. Reset overload.
	Water Cannon motor is defective.	Replace motor.
Centrifugal Pump motor hums but will not start.	Obstruction in pump.	Remove obstruction.
	3 phase motor supplied with Single phase.	Have electrician check and correct.
Centrifugal Pump won't prime.	Insufficient water in collection pit.	Add water or adjust floats.
	Lack of water in the pump housing.	Ensure all valves are in the correct position and the Prime Chamber is full of water.
	Blocked suction line or strainer.	Remove obstruction.
	Air leak in suction piping.	Correct air leak.
	Motor rotation is backward.	Have qualified electrician reverse rotation.
	No vacuum in pump.	Tighten all hardware on suction side of pump.
	Pump is obstructed.	Remove obstructions.
	Insufficient voltage.	Check voltage with voltmeter.
Centrifugal Pump has noisy operation.	Insufficient incoming water flow.	Blocked suction or strainer.
	Air leak in suction piping.	Correct air leak.
	Improper mounting causing vibration.	Ensure pump is mounted level with the unit base.
	Debris in pump.	Clean.
Centrifugal Pump has low output.	Undersized suction.	Correct pipe size or throttle discharge.
	Blocked suction line or strainer.	Remove obstruction.
	Air leak in suction piping.	Correct air leak.
	Suction lift too high.	Adjust plumbing.
	Plugged or restricted impeller.	Correct restriction.
	Low operating speed.	Correct voltage.
	Discharge line from Water Cannon is obstructed.	Remove obstruction.
	Pump is not primed.	See Priming Instructions, pg. 15.
	Plumbing is obstructed or too small.	Remove obstruction or use larger plumbing.
	Scale buildup in metal piping.	Clean or replace.

TROUBLESHOOTING

SYMPTOM	PROBABLE CAUSE	REMEDY
SHAFT SEALS		
Water is leaking at pumps.	Damaged stationary shaft seal.	Seal ran dry. Ensure seal chamber is filled with liquid.
Short seal life.	Unexpected temperature and chemical usage.	Replace.
WATER FLOW		
Air shoots from Water Outlet.	This is a common occurrence while pump is priming.	Air will stop shooting from the water outlet when pump is primed.]
Make-up water will not turn off.	Solenoid failure / float stuck.	Repair or replace.

ACCESSORIES

PART #	DESCRIPTION	WC-100-0ME3	WC-150-0ME3	WC-300-0ME3
50-2001	Hose Reel for 100' hose	X	X	--
15-2001	Hose-100' x 1 1/2"	X	X	--
18-2001	Nozzle-Adjustable	X	--	--
18-2002	Nozzle-Adjustable	--	X	--
18-2003	Nozzle-Adjustable	--	--	X
18-2004	Nozzle-Smooth Bore	--	--	X
18-2008	Nozzle-Smooth Bore	X	X	--
18-2007	Bale-Ball Shut off	X	X	--
18-2006	Monitor	--	--	X
18-2005	Gate Valve	--	--	X

STATEMENT OF WARRANTY

Mi-T-M warrants all parts (except those referred to below) of your new Water Cannon to be free from defects in materials and workmanship for one year from the date of original purchase.

Defective parts not subject to normal wear and tear will be repaired or replaced at Mi-T-M's option during the warranty period. In any event, reimbursement is limited to the purchase price paid.

EXCLUSIONS

1. Normal wear parts:

Seals	Filters
O-rings	Gaskets
2. Parts damaged due to:
 - normal wear, misapplication, modifications/alterations, abuse,
 - operation at other than recommended speeds, pressures or temperature,
 - the use of caustic liquids,
 - chloride corrosion or chemical deterioration,
 - fluctuations in electrical or water supply,
 - operating unit in an abrasive, corrosive or freezing environment.
3. Parts damaged by failure to follow recommended:
 - installation, operating and maintenance procedures.
4. This warranty does not cover the cost of:
 - normal maintenance or adjustments,
 - labor charges,
 - transportation charges to Service Center,
 - freight damage.
5. The use of other than genuine Mi-T-M parts will void warranty. Parts returned, prepaid to Mi-T-M's factory or to an Authorized Service Center will be inspected and replaced free of charge if found to be defective and subject to warranty. There are no warranties which extend beyond the description of the face hereof. Under no circumstances shall Mi-T-M bear any responsibility for loss of use of the unit, loss of time or rental, inconvenience, commercial loss or consequential damages.

Manufactured by Mi-T-M
8650 Enterprise Drive, Peosta IA 52068
563-556-7484/ Fax 563-556-1235